



7-2016

## INSTALLATION INSTRUCTIONS

## **SAFETY AND PROPER USAGE**


To ensure safe and enduring performance of this product, you must comply strictly with the instructions enclosed herein. Non-compliance with instructions or improper handling of the product will void your warranty! Usage of this product in conditions not specified in this manual or in contrary to the instructions hereby provided is considered IMPROPER. The manufacturer will not be held liable for any damages resulting from improper use of the product.





## **SAFETY & WARNING INSTRUCTIONS**

- Observe valid and generally accepted safety rules when planning, installing and using this product.
- Take proper measures to prevent unintentional operation of the product or damage to it.
- Do not attempt to disassemble this product or lines in the system while they are under pressure.
- Always depressurise the compressed air system before working on the system.

It is important that personnel use safe working practices and observe all regulations and legal requirements for safety when operating this product. When handling, operating or carrying out maintenance on this product, personnel must employ safe engineering practices and observe all local health & safety requirements & regulations. International users refer to regulations that prevail within the country of installation. Most accidents, which occur during the operation and maintenance of machinery, are the result of failure to observe basic safety rules or precautions. An accident can often be avoided by recognising a situation that is potentially dangerous. Improper operation or maintenance of this product could be dangerous and result in an accident causing injury or death. The manufacturer cannot anticipate every possible circumstance, which may represent a potential hazard. The WARNINGS in this manual cover the most common potential hazards and are therefore not all-inclusive. If the user employs an operating procedure, an item of equipment or a method of working which is not specifically recommended by the manufacturer he must ensure that the product will not be damaged or made unsafe and that there is no risk to persons or property.

## **NEVER CHANGE ORIGINAL COMPONENTS WITH ALTERNATIVES**





## INSTALLATION INSTRUCTIONS

*Before using this product, make sure it complies with your request and that it suits your application!*

---

1. Unpack the unit and visually inspect for any transport damage incurred after leaving our factory.

---

2. Depressurise the system before installation or maintenance is carried out!

---

3. Locate a suitable point in your compressor room to place the distributor. This point must be near your condensate cleaners.

---

4. Mount the distributor against the wall using the supplied screws and plugs.  
*- Use a spirit level to mount the distributor as level as possible!*

---

5. Connect the condensate collection pipe to the inlet of the distributor.

---

6. Connect the distributor outlets to the inlets of your condensate cleaners.  
*- Make sure the condensate always flows down!*

---

7. *OPTION: replace the outlet plug with the supplied outlet nipple to connect a third condensate cleaner to your distributor.*

---

8. Your distributor is now ready for operation.

## TECHNICAL SPECIFICATIONS

<b>Inlet connections</b>	1/2" brass (1*)
<b>Outlet connections</b>	1/2" brass (3*)
<b>Max. pressure</b>	15 BAR
<b>Housing material</b>	PA
<b>Housing colour</b>	Black
<b>Screws and plugs included</b>	Yes

## DIMENSIONS (mm)

